Example on programming instructions for Grippex

FANUC

:0001	SUB Program
G0 T1212 M5	
X0. Z30.	
G1 G98 Z-80. F3000	
М8	Coolant ON, Grippex clamp
G4 U1.	Dwell
M69	Chuck unclamp
G4 U0.1	Dwell
G1 Z-1.	Pulling-out the bar to a specific z-extent
M68	Chuck clamp
М9	Coolant OFF, Grippex unclamp
G0 G99 Z	Leave the bar
X	
M99	
8	

OKUMA

	SUB Program
G0 X0 Z55 T090909 G0 Z-2 M08 G04 F2 G0 M84 G04 F2 G0 Z M83 M09 G04 F03 G0 Z X Z	Change to Grippex (example) Approach bar to be pulled Coolant ON, Grippex clamp Dwell Chuck unclamp Dwell Pulling-out the bar to a specific z-extent Chuck clamp Coolant OFF, Grippex unclamp Dwell Leave the bar Return to Zero and calling a new tool
•	